


# Parquet Dance Floor

## INSTRUCTION MANUAL



### A Step by Step Guide on Assembling Your Floor


Thank you for purchasing Grumpy Joes Parquet Dance Floor System.  
Please read carefully through all the provided material before laying your floor.

Contents	Page
Laying Instructions.....	1-3
Floor Design.....	4
Component list .....	5
Maintenance .....	6
Warranty.....	7

## PARQUET DANCE FLOOR – LAYING INSTRUCTIONS


### 1 LAYING FIRST ROW OF PANELS

Start at the top left hand corner position by placing a full panel with the 3 end lugs pointing to the left. Then lay a second panel with the two end lugs pointing to the right. Add the next panel and so on for the size of floor length required.



### 2 FITTING EDGING

After completing the first row, fit the edging along the length. The edging lays in the same way as the floor panels (See *diagram 1*; page 2) and acts as a “straight edge” ensuring each row is square and flush as it is laid.



*The top row of edging should mirror the second row of panels, to stagger the joints and support the panel corners.*

*The edging row starts with a half edge (1.5ft long) then 2 full (3ft long) edges, and finishes with a half edge.*

## PARQUET DANCE FLOOR – LAYING INSTRUCTIONS

Half length (highlighted in red) and full length edges (highlighted in green) are supplied so the panel joints and the edging joints never coincide i.e. they follow the same brickwork pattern. Each floor will require 2 left corner edging pieces and 2 right corner edging pieces (highlighted in blue) which always go along the row ends.



*It may be helpful to have someone apply some weight to the first row when connecting the edging and when creating the second row to stop the floor sliding.*


### HOW TO FIT PANELS OR EDGING

Hold the panel or edging at an angle as in **diagram 1** below and push so the lugs slide under the panel. Lower the panel or edging whilst continuing the push, the lugs will connect the panels or edging and should sit flush with each other.

**DO NOT FORCE THE PANELS or EDGING DOWN** – simply adjust until they fit.

Continue to lay the row or edging in this manner. When connecting the floor panels together, use as many full panels as required for the size of the floor, be aware, the floor design can end in a half panel. The edging will be supplied to meet your floor size and will be a mixture of full and half lengths as well as the corners.


**Diagram 1:**  
*Connecting the floor panels*



## PARQUET DANCE FLOOR – LAYING INSTRUCTIONS

### 3 LAYING SECOND ROW OF PANELS

With the three end lugs pointing to the left as you look at the floor **begin the second row with a half panel**. Next lay full panels along the row; you should now have three end lugs pointing to the right from the second panel onwards. End the row with another half panel if required. Continue to lay alternate rows in this manner for the size of the floor.




### 4 LAYING THIRD ROW OF PANELS AND REMAINING FLOOR

Continue to lay the floor to the size required using full panels and half panels.

The 3<sup>rd</sup> row is laid in the same order as the 1<sup>st</sup>.

The 4<sup>th</sup> row is laid in the same order as the 2<sup>nd</sup> row, and so on.

This forms the brickwork pattern which cannot split apart in use.




A finished floor should have lugs on all the edges. Once you have laid the desired floor size, finish laying the edging on the remaining floor sides.

## PARQUET DANCE FLOOR – FLOOR DESIGN


At Grumpy Joes we suggest when designing the floor and deciding how many panels you want, you always start with the long-side first. For example a 9ft x 12ft floor, you design it to a 12ft x 9ft as shown below.

This way fewer panels are required, therefore there are less joints. This means that there is less to store and the floor is quicker to lay.

Example recommended design planning:




*11 Full panels  
2 half panels*



*10 Full panels  
4 half panels*

Example floor with edging:



- Corner
- Half Edge
- Full Edge

## PARQUET DANCE FLOOR – COMPONENTS LIST

### Component List (Working on the “long-side” design principle)

Floor Size	Full Panel	Half Panel	Full Edge	Half Edge	R/L Corner
9ft x 9ft	8	2	8	4	4
12ft x 9ft	11	2	10	4	4
12ft x 12ft	14	4	13	2	4
15ft x 12ft	18	4	15	2	4
15ft x 15ft	23	4	16	4	4
18ft x 15ft	28	4	18	4	4
18ft x 18ft	33	6	21	2	4
21ft x 15ft	33	4	20	4	4
21ft x 18ft	39	6	23	2	4
21ft x 21ft	46	6	24	4	4
24ft x 18ft	45	6	25	2	4
24ft x 21ft	53	6	26	4	4
24ft x 24ft	60	8	29	2	4
27ft x 27ft	77	8	32	4	4
30ft x 30ft	95	10	37	2	4



*This list is not exhaustive. Any size of floor can be made, increasing in 2ft steps of length or width.*

### Component Specifications

Full Panel	86.5x86.5x2.8cm	34x34x1.06in	11 kg	24.2 lbs
Half Panel	86.5x43.2x2.8cm	34x17x1.06in	5.5 kg	12.1 lbs
Full Edge	86.5x13x2.8cm	34x5.25x1.06in	1.5 kg	3.3 lbs
Half Edge	43.2x13x2.8cm	17x5.25x1.06in	0.8 kg	1.76 lbs
R/L Corners	56.2x13x2.8cm	22.1x5.25x1.06in	1 kg	2.2 lbs
Trolley	112x66x127cm	44x26x50in	26 kg	57.2 lbs
Full Trolley of a 15ft x 15ft Floor	112x66x127cm	44x26x50in	332.2 kg	732.4 lbs



In addition to the component list, our Floor Calculator app can be used to calculate a full breakdown of any floor size and provides a laying diagram.

Simply enter the type and size of floor, and instantly view a diagram of the selected floor with all components and weights. The Floor Calculator app is available for Apple or Android devices, or can be accessed directly from our website at [www.grumpyjoe.co.uk](http://www.grumpyjoe.co.uk).

## PARQUET DANCE FLOOR – PRODUCT SAFETY AND MAINTENANCE

---

The design of our Parquet Flooring System is highly reliable and hard wearing. The Parquet Dance Floor is made from real wood, so we expect the colour of the parquet panels to change slightly over time. The floor may come in to contact with minor spillages such as from drinks, it is durable enough to withstand such incidences but ideally would be cleaned up straight away. As with all of our products, we recommend regular cleaning and inspection schedules to be followed to ensure the continued functionality of your product.



### PRODUCT CARE AND MAINTENANCE

THIS PRODUCT SHOULD BE LAID ON A LEVEL, DRY, SOLID SURFACE.

- Must be stored in a cool, dry environment.
- Clean with a damp cloth or mild detergent.
- Should the floor get wet, immediately remove all liquid and dry thoroughly.
- Store in the appropriate trolley or on a flat secure surface.
- If cleaning with a mop, DO NOT clean with a wet mop, it should be damp.
- Store face-to-face and back to back when stacked.
- DO NOT use abrasive cleaners.



### PRODUCT SAFETY

- Caution should be used when wet as the floor can become slippery – where possible, remove any liquid and dry.
- Always ensure any panel edges or edging product is not protruding to cause a trip hazard.
- When using the dance floor, always wear appropriate footwear.
- Floor parts should be checked regularly, any foreign or metallic objects removed immediately.
- Always use appropriate lifting procedures and work wear when handling, fitting or moving the product.

*For further safety information, please ask for our risk assessment sheet.*

## PARQUET DANCE FLOOR – TERMS AND CONDITIONS

---

### Warranty for Grumpy Joes PARQUET Dance Flooring: 3 years Limited Warranty for interlocking system

For the warranty period indicated above, Grumpy Joes ("Manufacturer"), warrants to the Purchaser (Owner) that the Manufacturer will, subject to the Terms, Conditions, and Limitations set forth below, provide repair work or replacement of the Parquet Dance Floor or the option of a prorated credit (based upon the remaining months of the unexpired warranty) sufficient to replace any area of the Parquet Dance Floor as a result of any manufacturing defect in the floor interlocking system subject to exclusions (4) below to include all transport costs in the UK mainland only (Not including Northern Ireland). Grumpy Joes Ltd repair obligation over the life of this warranty is limited to the owner's original cost of the Parquet Dance Floor. All other repairs to be returned to the manufacturer at the owner's expense and the manufacturer will repair or replace at the owners expense subject to notice and investigation (2) set out below. The manufacturer warrants that the goods will be of satisfactory quality at the time of purchase and or delivery and the Manufacturer shall at its option refund the purchase price or replace free of charge any goods which are defective provided; (a) the owner makes a full inspection of the goods immediately upon delivery to include third party carriers delivery (b) Any delivery by a third party carrier has been checked thoroughly and the owner does not sign for damaged flooring (c) the owner notifies the manufacturer as laid out in notice and investigations 2(a) below.

### TERMS, CONDITIONS, AND LIMITATIONS

**1. Products Covered:** The Parquet Dance Floor is limited to mean the Manufacturer's Grumpy Joes Ltd Parquet Dance Floor when installed, maintained and stored in accordance with Manufacturer's Current Technical Specifications.

**2. Notice & Investigation:** In the event that a potential claim is suspected due to defective goods at time of delivery or of the interlocking system failure that would be covered by this warranty: (a) The Purchaser must give notice to the Manufacturer through e-mail, telephone call or in writing within **fourteen (14)** days of the discovery of a potential claim along with a copy of the purchase invoice and (if possible or appropriate) a sample picture of the defective panel from the Parquet Dance Floor.

By so notifying the Manufacturer, the Purchaser authorises the Manufacturer or its designee to investigate the claim. (b) If upon investigation, the Manufacturer determines that the fault is not excluded under the Terms, Conditions and Limitations set forth and is the result of less than expected Manufacturers floor performance or a manufacturing defect in the flooring at the time of manufacture, the Owner's sole and exclusive remedy and the Manufacturer's liability will be limited to providing repaired original or replacement flooring (or a prorated credit). (c) Should the investigation reveal that the damage is excluded under the Terms, Conditions, and Limitations set forth below, the Owner is responsible for payment of the investigation costs. Failure by the Owner to pay for these costs shall render the Parquet Dance Floor Product the property of the manufacturer until such time all payments are settled. The Manufacturer will advise the Owner of the type and/or extent of repairs required to be made at the Owner's expense that will permit this Limited Warranty to remain in effect for the unexpired portion of its term. Failure by the Owner to properly notify the manufacturer of the repair needs in a reasonable manner and within a reasonable time shall render this Limited Warranty null and void. (d) Any dispute, controversy or claim between the Owner and the Manufacturer concerning this Limited Warranty shall be settled by mediation. In the event that the Owner and the Manufacturer do not resolve the dispute, controversy or claim in mediation, the Owner and the Manufacturer agree that neither party will commence or prosecute any suit, proceeding or claim other than in the English courts governed by English Law. Each party irrevocably consents to the jurisdiction and venue of the identified English court as Nottingham County Court, 60 Canal Street, Nottingham, NG1 7EJ

**3. Payment Required:** The Manufacturer shall have no obligation under this Limited Warranty unless and until the Manufacturer has been paid in full for all materials, supplies, services, warranty costs and other costs which are included in, or incidental to, the Parquet Dance Floor and, or including, the interlocking system.

**4. Exclusions:** The Manufacturer shall have no obligation under this Limited Warranty, or any other liability, now or in the future if damage to the floor and its parts or surrounding environment is caused by: (a) Natural forces, disasters, accidents or incidents including, but not limited to, wind, hurricanes, tornadoes, hail, lightning, earthquakes, atomic radiation, insects, or animals; a "force Majeure"; (b) Any act(s), conduct or omission(s) by any person, or act(s) of war, which damages the Parquet Dance Floor or which impairs the Parquet Dance Floor system; (c) Failure by the Owner to use reasonable care in maintaining the Parquet Dance Floor, said maintenance to include, but not limited to those items listed in the Parquet Dance Floor "Parquet Dance Floor Instruction Manual" manual page titled "Parquet Dance Floor – Product Safety and Maintenance" (d) Condensation or excessive infiltration of moisture in, through, or around the flooring panels; (e) Excessive environmental forces such as heat directly or indirectly to include but not limited to Theatre lights, direct sunlight, fire or cold temperatures; (f) Excessive wear and tear beyond normal tolerances of the Manufacturers expectation of flooring performance; (g) Any acid, oil, harmful chemical, chemical or physical reaction and the like which comes in contact with the Parquet Dance Floor; (h) Alterations or repairs to the Parquet Dance Floor not approved in writing by Grumpy Joes authorised person(s); (i) A change in use or purpose; (j) Poor or improper installation; (k) Use of the product inconsistent with the safety standards in force in the country where it is used and product safety recommendations as written in the manufacturers instructions manual; (L) Damage to the product components or laying surface caused by accidents including but not limited to exclusion 4(k) and misuse or neglect; (m) Failure to give proper notice as set forth in paragraph 2(a) above; (n) Carriers damage to include signed paperwork by the Owner of the floor that has not been checked thoroughly for damage in transit as, signed delivery of the flooring by the Owner deems the floor in a satisfactory condition at the point of delivery making any application by the Manufacturer on the Owners behalf against the carrier null and void and as such, no claim by the Owner as set forth in section (2) Notice & Investigation above can be made.

**5. Exceptions:** In no event shall The Manufacturer be liable for personal injury or death, incidental or consequential to include, but not limited to the public and/or the buyer/Owner.

**6. Waiver:** The Manufacturer's failure to enforce any of the terms or conditions stated herein shall not be construed as a waiver of such provision or of any other terms and conditions of this Limited Warranty and shall no way affect the manufacturers right to enforce provision at a later date.

**7. Limits:** The surface of the dance floor is coated in a UV cured polymer lacquer. This can be scratched by, but not limited to shoe soles, high heels, grit, sand, stones or broken glass being ground into the surface. Scratches or damage to the surface of the Parquet is not covered by this Limited Warranty and care should be taken to look after the surface as explained in the user's manual.

THE MANUFACTURER DOES NOT WARRANT PRODUCTS INCORPORATED OR UTILISED IN ANY INSTALLATION THAT IT HAS NOT FURNISHED. THE MANUFACTURER SPECIFICALLY DISCLAIMS LIABILITY, UNDER ANY THEORY OF LAW, ARISING OUT OF THE INSTALLATION OR PERFORMANCE OF, OR DAMAGES SUSTAINED BY OR CAUSED BY, PRODUCTS NOT FURNISHED BY THE MANUFACTURER. THIS LIMITED WARRANTY SUPERSEDES AND IS IN LIEU OF ALL OTHER WARRANTIES OR GUARANTEES WHETHER WRITTEN OR ORAL, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANT ABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THIS LIMITED WARRANTY SHALL BE THE OWNER'S SOLE AND EXCLUSIVE REMEDY AGAINST THE MANUFACTURER AND THE MANUFACTURER SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL, SPECIAL, INCIDENTAL OR OTHER DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS. THIS LIMITED WARRANTY CANNOT BE AMENDED, ALTERED OR MODIFIED IN ANY WAY EXCEPT IN WRITING SIGNED BY AN AUTHORISED OFFICER OF THE MANUFACTURER. NO OTHER PERSON HAS ANY AUTHORITY TO BIND GRUMPY JOES WITH ANY REPRESENTATION OR WARRANTY WHETHER ORAL OR WRITTEN.